

ULTRASONIC 2513

ALUMINUM STRIPPER IN ULTRASONIC MACHINE

ULTRASONIC 2513 is a specially formulated product to be used as an acid cleaner and stripper of aluminum parts by immersion in ultrasonic cleaning machines.

DOSAGE AND MODE OF USE

You must use ULTRASONIC 2513 water diluted in the tank of the ultrasonic cleaning machine at a rate between 3 and 6%, with a temperature of bath between 30 and 60°C. It is recommended additive the bath with ULTRASONIC A between 0.1 and 0.2% to improve the result.

TECHNICAL CHARACTERISTICS

COLOUR	COLOURLESS
ASPECT	LIQUID
ODOUR	CHARACTERISTIC
DENSITY	1,12 +/- 0,05 g/cm ³
pH 1%	0,5 +/- 0,5

CONTAIN

15 – 30 %	Inorganic acids
-----------	-----------------

This product meets the existing legislation on biodegradability and the technical regulations of health on detergents.

www.tierratech.com